

American Bath Enterprises, Inc. (ABE)

PO Box 156 Hayward, CA 94557

(888) 228-4925 Fax: (510) 785-6300

E-Mail: Info@Americanbathind.com * Website: www.Americanbathind.com

AmeriWall™ Shower and Bath Wall Enclosure Installation Instructions

Suggested Tools:

Angle grinder with 4½" metal cutting disc or jigsaw
Caulking gun
Denatured Alcohol
Hole saw or drill
Measuring tape
Safety goggles
Straight edge
Utility knife

Adhesives:

8-9 Tubes- LOCTITE Power Grab or compatible construction grade adhesive for tub surround
1 Tube- DAP 100% Silicone White
1 Tube- ALEX Painter's Acrylic Latex Caulk

Preparations:

Complete any necessary plumbing before installing AmeriWall™ enclosure. ABE recommends that you install AmeriWall™ bath and shower wall enclosures over building code approved moisture-resistant sheetrock or other solid surface wallboard materials.

Installation Instructions:

Step One: Dry-fit the panels.

a) Before applying adhesive, dry-fit all the wall panels on top of the bath tub or shower pan.

Step Two: Measure the width of the back panel and trim left vertical side if needed.

Step Three: Drill plumbing holes.

a) Carefully measure and drill holes in the panel to accommodate the shower head arm and mixing valve.
b) Make sure the plumbing protrudes through panel when the panel is put into position.

American Bath Enterprises, Inc. (ABE)

AmeriWall™ Installation Instructions

Step Four: Apply adhesive to left panel. Place the panel in position and apply pressure top to bottom on the panel.

Step Five: Pull the panel away from the wall to allow the adhesive to de-gas and become tacky. Inspect wall and apply adhesive to fill the gaps where the wall doesn't make contact.

Step Six: Apply a bead of silicone caulk to the channel on the right side of the panel and the top of the tub or the shower pan where the panels will rest.

Step Seven: Repeat step four through six for back panel.

Step Eight: Repeat step four through five for right panel.

Step Nine: Trim the leg kit to fit the height and contour of the tub and mount with construction grade adhesive.

Step Ten: Clean all seams where the panels are joined and meet the tub or shower pan with Denatured Alcohol before applying silicone caulk.

Step Eleven: Caulk all outside perimeter seams with acrylic latex caulk. Include the edges and the top of the panels.

CAUTION

Liquid adhesive: Construction-grade adhesive and caulks tend to be very flammable. When using the liquid adhesive for installing AmeriWall™ products, be sure to follow the manufacturer's instructions and warnings.

Acrylic cleaning instructions: Wash with mild soap/detergent and lukewarm water, using a clean cloth or sponge. Rinse well and blot dry with a damp cloth or chamois. For stubborn stains or scuff marks, use Gel Gloss, an excellent one-step cleaner and polishing product, or any other acrylic friendly cleaning products available at most local hardware stores. For soap scum, use any acrylic friendly soap scum remover that should also be available at most hardware stores.

Abrasive cleaners: Never use abrasive cleaners, strong household cleaners, window cleaning fluids, scouring compounds, gritty cloths or solvents on AmeriWall™ surfaces.