

American Bath Enterprises, Inc.

PO Box 156 Hayward, CA 94557

(888) 228-4925 Fax: (510) 785-6300

E-Mail: Sales@Americanbathind.com * Website: www.Americanbathind.com

AmeriWall™ Corner Shelf Installation Instructions

(Installation instruction video is available for viewing on our website)

You will need 1 tube Liquid Nails Construction Adhesives (LN-990) or compatible construction grade adhesive for tub and shower surround, 1 tube of DAP 100% Silicone White and Denatured Alcohol.

Installation Instructions:

- Step One:** Dry-fit corner shelf on desire location.
- Step Two:** For model CS-1610 only, if the protective tape strips in the back of the corner shelf are not touching the walls, grind down the side edges before removing the protective strips.
- Step Three:** For model CS-1610 only, apply 2 zigzag lines of Loctite between tape strips to secure shelf in place.
- Step Four:** Install corner shelf and apply pressure to both sides.
- Step Five:** Clean the outside perimeter with Denatured Alcohol
- Step Six:** Apply White silicone caulk to all outside seams.

CAUTION

Liquid adhesive: Construction-grade adhesive and caulks tend to be very flammable. When using the liquid adhesive for installing AmeriWall™ products, be sure to follow the manufacturer's instructions and warnings.

Acrylic cleaning instructions: Wash with mild soap/detergent and lukewarm water, using a clean cloth or sponge. Rinse well and blot dry with a damp cloth or chamois. For stubborn stains or scuff marks, use Soft Scrub, an excellent one-step cleaner and polishing product, or any other acrylic friendly cleaning products available at most local hardware stores. For soap scum, use any acrylic friendly soap scum remover that should also be available at most hardware stores.

Abrasive cleaners: Never use abrasive cleaners, strong household cleaners, window cleaning fluids, scouring compounds, gritty cloths or solvents on AmeriWall™ surfaces.