

American Bath Enterprises, Inc.

26247 Research Place, Hayward, CA 94545

(888) 228-4925 Fax: (510) 785-6300

E-Mail: Sales@Americanbathind.com * Website: www.Americanbathind.com

AmeriWall™ Shower and Bath Wall Enclosure Installation Instructions

(Installation instruction video is available for viewing on our website)

Suggested Tools:

Angle grinder with 4½" metal cutting disc or jigsaw
Caulking gun
Drill and hole saw
Measuring tape
Safety goggles
Straight edge
Utility knife

Adhesives:

12 Tubes- Liquid Nails Construction Adhesives (LN-990) or compatible
construction grade adhesive for tub and shower surround
1 Tube- DAP 100% Silicone White or TG 400 (for corner seams)
1 Tube- DAP ALEX Painter's Acrylic Latex Caulk or TG 210 (for outside seams)

Preparations:

Complete any necessary plumbing before installing AmeriWall™ enclosure. ABE recommends that you install AmeriWall™ bath and shower wall enclosures over building code approved moisture-resistant sheetrock or other solid surface wallboard materials. NOTE: The wallboard material should not touch or overlap the vertical mounting flange of the bathtub or shower pan. For best results, leave a 1/8" gap between the bottom of the wallboard and the top of the vertical mounting flange.

Installation Instructions:

Step One: Dry-fit the panels. Before applying adhesive, dry-fit all the wall panels on top of the bath tub or shower pan.

Step Two: Measure the width of the back panel and trim left vertical side if needed.

Step Three: Drill plumbing holes.

- a) Carefully measure and drill holes in the panel to accommodate the shower head arm and mixing valve.
- b) Make sure the plumbing protrudes through panel when the panel is put into position.

AmeriWall™ Shower and Bath Wall Enclosure Installation Instructions

Step Four: Apply adhesive to left panel. Place the panel in position and apply pressure top to bottom on the panel.

Step Five: Pull the panel away from the wall to allow the adhesive to de-gas and become tacky. Inspect wall and apply adhesive to fill the gaps where the wall doesn't make contact.

Step Six: Apply a bead of silicone caulk to the channel on the right side of the panel and the top of the tub or the shower pan where the panels will rest.

Step Seven: Repeat step four through six for back panel.

Step Eight: Repeat step four through five for right panel.

Step Nine: Trim the leg kit to fit the height and contour of the tub/shower pan and mount with construction grade adhesive of needed.

Step Ten: Clean all seams where the panels are joined and meet the tub or shower pan before applying 100% white silicone caulk.

Step Eleven: Caulk all outside perimeter seams with acrylic latex caulk. Include the edges and the top of the panels.

CAUTION

Liquid adhesive: Construction-grade adhesive and caulks tend to be very flammable. When using the liquid adhesive for installing AmeriWall™ products, be sure to follow the manufacturer's instructions and warnings.

Acrylic cleaning instructions: Wash with mild soap/detergent and lukewarm water, using a clean cloth or sponge. Rinse well and blot dry with a damp cloth or chamois. For stubborn stains or scuff marks, use Soft Scrub, an excellent one-step cleaner and polishing product, or any other acrylic friendly cleaning products available at Walmart or local hardware stores. For soap scum, use any acrylic friendly soap scum remover that should also be available at most hardware stores.

Abrasive cleaners: Never use abrasive cleaners, strong household cleaners, window cleaning fluids, scouring compounds, gritty cloths or solvents on AmeriWall™ surfaces.